## SIMATIC 300(1)

UR - Rack (0)

Short description: UR

Order no.: 6ES7 390-1???0-0AA0

Designation: H1-UR

Rack (0), Slot 2

Short description: CPU 314C-2 PN/DP

Firmware version: V3.3

Order no.: 6ES7 314-6EH04-0AB0 Designation: CPU 314C-2 PN/DP

Width: 1

Comment:

Accessories:

Memory Card MMC 512KB (6ES7953-8LJ31-0AA0 )

Rack (0), Slot 2, Interface X1

Short description: MPI/DP
Order no.: --Designation: MPI/DP
Width: 1
PROFIBUS address: 2
Highest PROFIBUS address: 126

Baud rate: 1.5 Mbps Comment: - - -

Addresses Inputs

> Start: 2047 End: 2047

Synchronization mode: None Time interval: None

Operating mode: DP Master

Rack (0), Slot 2 Interface X2

Short description: PN-IO
Device name: PN-IO
Support device replacement without Yes

exchangeable medium:

IP address: 192.168.8.29

Comment

---Diagnostic addresses

Interface: 2046 Controller: 2043

\_

Send clock: 1.000
Communication allocation (PROFINET 0.0

IO):

Communication allocation (PROFINET - - -

CBA):

OB82 call after communication Disabled

interrupt:

Name of sync domain: syncdomain-default Synchronization role: Not synchronized

RT class: RT;IRT IRT option: - - -

SIMATIC

Media Redundancy Protocol (MRP)

Name of the MRP domain: mrpdomain-1

Role in the domain: Not node in the ring

Rack 0, Slot 2, Interface X2 P1 R

Short description Port Device name Port 1

 ${\tt Comment}$ 

Diagnostic address 2045\*

Interconnection

Local port: SIMATIC 300(1)\PN-IO\Port 1 (R0/S2/X2 P1 R)

Partner port: Any partner

Cable

Medium: Copper Cable name: Copper

Cable length: < 100 m (Signal delay time: 0.60  $\mu s$ )

Delay time: 0.60 µs

Connection

Transmission parameters: Automatic settings

Monitor: No Disable autonegotiation: No

Boundaries

End of sync domain: No End of detection of accessible No

nodes:

End of topology discovery: No

Rack 0, Slot 2, Interface X2 P2 R

Short description Port Device name Port 2

Comment

Diagnostic address 2044\*

 ${\tt Interconnection}$ 

Local port: SIMATIC 300(1)\PN-IO\Port 2 (R0/S2/X2 P2 R)

Partner port: Any partner

Cable

Medium: Copper Cable name: Copper

Cable length: < 100 m (Signal delay time: 0.60  $\mu$ s)

Delay time: 0.60  $\mu s$ 

Connection

Transmission parameters: Automatic settings

Monitor: No Disable autonegotiation: No

Boundaries

End of sync domain: No
End of detection of accessible No

nodes:

End of topology discovery: No

Rack (0), Slot 2, Interface 5

Short description: DI24/D016
Order no.: - - Designation: DI24/D016
Digital channels: 24 Inputs
16 Outputs

Width:

```
Comment:
 Addresses
   Inputs
     Start:
                                        4
     End:
                                        6
   Outputs
                                        4
     Start:
                                        5
      End:
Rack (0), Slot 2, Interface 6
  Short description:
                                       AI5/A02
  Order no.:
                                       AI5/AO2
  Designation:
                                        5 Inputs
  Analog channels:
                                        2 Outputs
  Width:
  Comment:
  Addresses
   Inputs
                                        128
     Start:
                                        137
     End:
    Outputs
                                        128
      Start:
      End:
                                        131
Rack (0), Slot 2, Interface 7
  Short description:
                                        Count
  Order no.:
  Designation:
                                        Zählen
  Width:
                                        - - -
  Comment:
  Addresses
    Inputs
                                        256
     Start:
                                        271
     End:
    Outputs
                                        256
      Start:
      End:
                                        271
Rack (0), Slot 2, Interface 8
  Short description:
                                        Position
  Order no.:
  Designation:
                                        Positionieren
  Width:
  Comment:
  Addresses
    Inputs
                                        272
     Start:
     End:
                                        287
    Outputs
                                        272
      Start:
      End:
                                        287
Rack (0), Slot 4
  Short description:
                                        DO16xDC24V/0.5A
  Order no.:
                                        6ES7 322-1BH01-0AA0
                                       DO16xDC24V/0.5A
  Designation:
                                       16 Outputs
  Digital channels:
  Width:
  Comment:
  Addresses
    Outputs
      Start:
                                        10
                                        11
      End:
```

```
Rack (0), Slot 5
  Short description:
                                      DI16xDC24V
  Order no.:
                                      6ES7 321-1BH02-0AA0
                                      DI16xDC24V
 Designation:
  Digital channels:
                                      16 Inputs
  Width:
  Comment:
                                       - - -
  Addresses
    Inputs
                                       10
     Start:
     End:
                                       11
DP master system:
  Assigned master:
    Short description
                                      MPI/DP
    Order no.
    Designation
                                       MPI/DP
    Location
                                       SIMATIC 300(1)
     Station
     Rack
     Receptacle for interface module 1
    PROFIBUS address
    Group: 1
    Comment:
    The group supports SYNC.
    The group supports FREEZE.
    Group: 2
    Comment:
    The group supports SYNC.
    The group supports FREEZE.
    Group: 3
    Comment:
    The group supports SYNC.
    The group supports FREEZE.
    Group: 4
    Comment:
    The group supports SYNC.
    The group supports FREEZE.
    Group: 5
    Comment:
    The group supports SYNC.
    The group supports FREEZE.
    Group: 6
    Comment:
    The group supports SYNC.
    The group supports FREEZE.
```

```
Group: 7
   Comment:
   The group supports SYNC.
   The group supports FREEZE.
   Group: 8
   Comment:
   The group supports SYNC.
   The group supports FREEZE.
  Slave : Gateway DFP/DFS PROFIBUS address: 4
  Assigned to the groups:
Slave (4)
                                       U1 Gateway DFP/DFS
  Order number:
  Family:
                                       Drives
  DP slave type:
                                       Gateway DFP/DFS
  Manufacturer:
                                       SEW-EURODRIVE
  GSD file name:
                                       SEW 6009.GSD
  GSD revision:
  Identification number:
                                       0x6009
  Revision of the DP slave:
                                       1.1
  Hardware release:
                                       10
  Software revision level:
                                       10
                                       U1.1: Rot.Feeder HP01/HP02
  Comment:
  U1.2: ...
  U1.3: ...
  U1.4: ...
  U1.5: ...
  U1.6: ...
  U1.7: ...
  U1.8: ...
  PROFIBUS address :
                                        4
                                        2042
  Diagnostic address:
  SYNC:
                                       Yes
  FREEZE:
                                       Yes
                                       Turned on
  Watchdog:
  Parameter assignment in ascending byte sequence (hexadecimal specification) :
  C4,00,00
DP ID:
                                        0
Module description:
                                        Empty
DP ID:
                                        192
Module description:
                                        Parameter channel (8 byte)
Input address:
                                        400
Output address:
                                        400
DP ID:
                                       192
Module description:
                                       AS 1 Drive (1 \times 3 \text{ PD})
Input address:
                                        408
Output address:
                                        408
PROFINET IO System:
Short description
                                        PROFINET IO system
Name
                                        PROFINET-IO-System
IO system No.
                                        100
Subnet
                                       Ethernet (1)
Communication Allocation (PROFINET
                                       0.0 %
IO)
```

SIMATIC

1.000 ms

Comment:

Send clock